

	p/stuk	p/paar
TABLETTE TEN ebony / rosewood	900 1000	1800 2000
TABLETTE TEN SIGNATURE ebony / rosewood	1050 1200	2100 2400
TABLETTE CENTRE VOICE	1100	
STUDIO MONITOR SM100	1350	2700
RESPONSE DB 3 ebony / rosewood	1150 1400	2300 2800
RESPONSE DB 1 ebony / rosewood	1500 1800	3000 3600
RESPONSE D 2 ebony / rosewood	1800 2100	3600 4200
RESPONSE D 2 Ribbon ebony / rosewood	1950 2400	3900 4800
RESPONSE DT 8 ebony / rosewood	1600 1950	3200 3900
RESPONSE D 20 Ribbon of Dome Tweeter ebony / rosewood	2300 2600	4600 5200
RESPONSE D 30 Ribbon of Dome Tweeter ebony / rosewood	3750 4250	7500 8500
RESPONSE D 48 Ribbon of Dome Tweeter ebony / rosewood	4750 5500	9500 11000
RESPONSE K1 ebony / rosewood / Tamo Ash / Dark Eucalyptus	4250 5000	8500 10000
RESPONSE K3 ebony / rosewood	7250 8500	14500 17000
RESPONSE K6 ebony / rosewood	9750 11250	19500 22500
RESPONSE K6 Signature ebony / rosewood / Tamo Ash / Dark Eucalyptus	13250 14750	26500 29500
RESPONSE K10 ebony / rosewood / Tamo Ash / Dark Eucalyptus	23750 26250	47500 52500

Standaard uitvoeringen :

Tab 10, Tab 10 Sig, Centre Voice, DB3, DB1, D2, DT8, D20, D30, D48, K1, K3, K6, K10
black ash, silk white, cherry, maple, mahogany, natural oak

